

同悦车 ABS 故障代码

C 1101 0x5101 0100 ECU Voltage supply: high voltage

ECU 的电压供应：高压

C 1102 0x5102 0100 ECU Voltage supply: low voltage

ECU 的电压供应：低电压

C 1200 0x5200 0100 Wheel-speed sensor, front left: open/short

轮速传感器，左前方：开路/短路

C 1201 0x5201 1000 Wheel-speed sensor, front left: range,performance,intermittent

轮速传感器，左前：范围，性能，间歇

C 1202 0x5202 0100 Wheel-speed sensor, front left: invalid/no signal

轮速传感器，左前：无效的/无信号

C 1203 0x5203 0100 Wheel-speed sensor, front right: open/short

轮速传感器，前右：开路/短路

C 1204 0x5204 1000 Wheel-speed sensor, front right: range,performance,intermittent

轮速传感器，前右：范围，性能，间歇

C 1205 0x5205 0100 Wheel-speed sensor,front right:invalid/no signal

轮速传感器，前右：无效的/无信号

C 1206 0x5206 0100 Wheel-speed sensor,rear left:open/short

轮速传感器，后排左起：开路/短路

C 1207 0x5207 1000 Wheel-speed sensor,rear left:range,performance,intermittent

轮速传感器，左后：范围，性能，间歇

C 1208 0x5208 0100 Wheel-speed sensor,rear left:invalid/no signal

轮速传感器，左后：无效的/无信号

C 1209 0x5209 0100 Wheel-speed sensor,rear right:open/short

轮速传感器，右后轮：开路/短路

C 1210 0x5210 1000 Wheel-speed sensor,rear right:range,performance,intermittent

轮速传感器，右后轮：范围，性能，间歇

C 1211 0x5211 0100 Wheel-speed sensor,rear right:invalid/no signal

轮速传感器，右后轮：无效的/无信号

C 1213 0x5213 0100

Wheel-speed sensor frequency error(generic wheel speed-sensor
error, slipping or wrong toothed)

轮速传感器的频率误差（通用轮速传感器错误，滑倒或错误的齿）

C 1604 0x5604 0100 ECU hardware error

ECU 的硬件错误

C 2112 0x6112 0100 Valve relay error

阀门中继错误

C 2308 0x6308 0100 valve fault,inlet valve FL

阀门故障，进气阀

C 2312 0x6312 0100 valve fault,outlet valve FL

阀门故障，排气阀

C 2316 0x6316 0100 valve fault,inlet valve FR

阀门故障，进气阀阻燃

C 2320 0x6320 0100 valve fault,outlet valve FR

阀门故障，排气阀阻燃

C 2324 0x6324 0100 valve fault,inlet valve RL

阀门故障，进气阀 RL

C 2328 0x6328 0100 valve fault,outlet valve RL

阀门故障，排气阀 RL

C 2332 0x6332 0100 valve fault,inlet valve RR

阀门故障，进气阀

C 2336 0x6336 0100 valve fault,outlet valve RR

阀门故障，排气阀

C 2402 0x6402 0100 Return pump fault (motor electrical)

返回泵故障（电机电器）